

Kitchen Strainer Drain

This procedure will assist you with installing the Sinkology Basket Strainer Drain.

GETTING STARTED

- DIY

You will need: To complete this procedure, you will need Plumbers Putty.

Strainer Drain Installation Instructions are available on the BILT® App. Download the BILT App today and search "Sinkology" to find install instructions specifically for your product and installation type or scan the QR Code for easy access.

SCAN FOR BILT 3D INSTRUCTIONS



POWERED BY BILT INTELLIGENT INSTRUCTIONS

INSTRUCTIONS

1. Remove the Strainer from the Basket Strainer Drain Assembly. Unscrew the Nut and the Large Metal Nut from the bottom of the Drain Assembly. Remove the Flat Washer and the Rubber Washer.
2. Apply Plumbers Putty around the underside of the outer Drain flange lip.
3. Place the Basket Strainer Drain in the drain hole of the Sink. The metal flange will sit directly on the Sink.
4. Place the Nut on the Drain Pipe.
5. Place the Rubber Washer and the Flat Washer on the Basket Strainer Drain and screw on the Large Metal Nut.
6. Secure the Drain Pipe to the Basket Strainer Drain using the Nut.
7. Clean off any excess Plumbers Putty.
8. Place the Strainer in the Basket Strainer Drain.

Congratulations, this completes the installation of the Sinkology Strainer Drain.

LIFETIME WARRANTY

All Sinkology products are fully backed with a lifetime warranty - the Sinkology Everyday Promise.



SHOW US YOUR SINK

Join our online community of thousands of happy customers who are showcasing our products in their homes to automatically be entered into our **\$1,000 gift card giveaway**.

Visit Sinkology.com/ShowUsYourSink for more details.